



No.	Parts Description
1	FRONT PANEL
2	CHASSIS BASE
3	M/B MOUNTING DRAWER
4	COVER
5	I/O PANEL
6	GROUNDING COPPER SCREW
7	RUBBER FOOT
8	CARD GUIDE/FAN HOLDER
9	SPEAKER
10	H.D.D. BRACKET
11	KEY FLAP
12	#6*32 SCREW
13	PCB SPACER
14	GROUNDING CLIP
15	EMI/DO SHIELD

PARCEL LIST											
Parts Description	QTY	Diagram	Parts Description	QTY	Diagram	Parts Description	QTY	Diagram	Parts Description	QTY	Diagram
GROUND COPPER SCREW	9		M3*5 SCREW	29		I/O PANEL	6		RUBBER FOOT	4	
#6*32 4.5SCREW	13		#6*32 SCREW	8		KEY FLAP	1		PCB SPACER	1	

IW-A500-ATX